





# Hot Pad Quilt Block Project Guide

A decorative black flourish consisting of three interlocking loops, positioned below the title.

Choose any  
6", 7", or  
8" block

**Remember:** Complete the stitching instructions for your chosen block design up to the red **STOP** notation. You'll then come back to these instructions to finish the project.

### *Additional Supplies you'll need...*

- Fabric for Back, Fat Quarter
- 1" wide Fusible Seam Tape

**\*\*\* You MUST use insulated batting when stitching your block!**

All measurements are listed width x length.


### *Prep your fabrics...*

#### *Cut Fabric...*


For:	Label:	8" Block	7" Block	6" Block
Back piece 1	1	10" x 4"	9" x 4"	8" x 4"
Back piece 2	2	10" x 10"	9" x 9"	8" x 8"

#### *Other Fabric Prep...*

- Fabric 1: fold back 1" lengthwise, wrong sides together. Press.



- Fabric 1: Press fusible seam tape along the right side of the fold, as shown. Leave any paper backing on the tape intact for now.




# Let's Stitch...


You should have your block design completed until the red **STOP** in the block instructions. **Leave the project hooped** and follow the steps below to complete the project...

1. Remove the hoop from your machine, but leave the project in the hoop. Carefully remove any tape around the project.


Using a ruler and pen, measure down 2" from the top left stitch line. Mark this outside the left stitch line as indicated by the arrow in the picture.




2. Repeat on the right side, marking 2" down from the top stitch line and marking outside the stitch line.




3. Place Fabric 1 over the top of the project, right side down, with the fold facing the center of the hoop. Align the fold just above the lines you drew in steps 1 and 2. Tape in place along the raw edges.



4. Place Fabric 2 over the bottom of the project, right side down, with the top edge overlapping Fabric 1 by 1". Tape in place on the sides and lower edge.




5. To prevent the presser foot from catching as it sews the next stitch sequence, place tape across the entire top edge of Fabric 2.




7. Remove the hoop from your machine and take the project out of the hoop. Remove the tape.

Trim around the project, leaving a 1/2" seam allowance, and clip the corners.




6. Put the hoop back on your machine.

Sew the final stitch sequence to stitch the layers together.



8. Turn the project, right side out, through the opening in the back. Poke out the corners.

Pull off any paper backing on the seam tape. Iron the back of your project over the opening to allow the seam tape to fuse it closed.



9. Press the rest of the project to complete your hot pad!

